LifeCycle Recumbent Bike - Model LC85R-0100-28 S/N CEH100001

Unit Assembly



Operation Manual	M051-00K20-A347
Service Manual	M051-00K39-A012

NOTE: Optional Polar Accessory Kit, GK39-00002-0001.

Console Overlay Bezel Assembly



LC8500 Recumbent			
Console Assembly	**Overlay Bezel**	**Upper Overlay**	**Lower Overlay**
AK63-00072-0001 Eng Met	AK63-00080-0001 Eng Met	0K63-01104-0001 Eng Met	0K63-01106-0001 Eng Met
AK63-00072-0003 Ger Met	AK63-00080-0003 Ger Met	0K63-01104-0003 Ger Met	0K63-01106-0003 Ger Met
AK63-00072-0004 Spn Met	AK63-00080-0004 Spn Met	0K63-01104-0004 Spn Met	0K63-01106-0004 Spn Met
AK63-00072-0006 Jap Met	AK63-00080-0006 Jap Met	0K63-01104-0006 Jap Met	0K63-01106-0006 Jap Met
AK63-00072-0007 Frn Met	AK63-00080-0007 Frn Met	0K63-01104-0007 Frn Met	0K63-01106-0007 Frn Met
AK63-00072-0008 Itl Met	AK63-00080-0008 Itl Met	0K63-01104-0008 Itl Met	0K63-01106-0008 Itl Met
AK63-00072-0009 Itl Met	AK63-00080-0009 Itl Met	0K63-01104-0009 Itl Met	0K63-01106-0009 Itl Met
AK63-00072-0010 Por Met	AK63-00080-0010 Por Met	0K63-01104-0010 Por Met	0K63-01106-0010 Por Met

Console Support Assembly



Shrouds, End Cap, and Pedals



Wheel and Leveler



Belts and 6V Battery



Resistor Assembly



Power Control Board - AK39-00022-0002



Alternator w/Pulley - AK63-00093-0000



Crank Shaft and Bearing Assembly – GK63-00002-0006 Kit



Intermediate Shaft and Bearing Assembly – GK63-00002-0007 Kit



Idler Bracket Assembly – AK63-00021-0000



Seat Assembly



Seat Assembly - Bottom



Seat Frame Assembly



Seat Pads and Accessory Tray



Extrusion Assembly



Lock Assembly AK51-00053-00000



Cable – Block Assembly